

Alden Foot Balance System advertisement.

[s.l.]: [s.n.], 1974

https://digital.library.wisc.edu/1711.dl/VVYZ7TOJD5MSV8V

http://rightsstatements.org/vocab/InC/1.0/

The libraries provide public access to a wide range of material, including online exhibits, digitized collections, archival finding aids, our catalog, online articles, and a growing range of materials in many media.

When possible, we provide rights information in catalog records, finding aids, and other metadata that accompanies collections or items. However, it is always the user's obligation to evaluate copyright and rights issues in light of their own use.



Where corrections call for maximum space in the forepart of a shoe, the need for heel control requires precise last design.

For example, in the case of the heavy foot, square fore foot, and splay foot, the shoe should provide a broad ball tread, maximum lateral displacement, and a high and wide toe last.

But the foot can't be allowed to slide forward or rotate within the shoe. In other words, the shoe should be snug, but it should

be roomy.

That's the Alden Trubalance Last. In dress or work styles.

For information on this or any other Alden last, contact your orthopedic shoe specialist, or write: Alden Shoe Co., Middleborough, Mass. 02346.

THE ALDEN FOOT BALANCE SYSTEM.



